

# 1105

A. Pour Concrete 13 ½"-15"

B. Bolts should be 4 ½"  
into the concrete till  
touching the triangle



