



Assembly Instruction For 12053

1. Place the diffuser 1 on the nipple 2, then secured by the finial 1
2. put the tube on the coupler, then insert the nipple 1 into it till tighten
3. Put metal cover 1, diffuser 2 and the shade into the frame, place the metal cover 2 on the shade
4. Put the small cover 2 under the frame then secured all the above parts together by nipple 3 and finial 2

