

Assembly Instruction For 13504

- 1. Thread the nipple into the coupler then secure by hex nut.
- 2.Attached the cap and top part on the nipple then secure by loop.
- 3.Place the glass over the socket then secure by socket ring.

