

# MAXIM Assembly Instruction For 21340

1. Put glass shade(C) into metal(A) ;
2. Put Cap(D) into nipple(B) ,then secured nipple(B) by hexnut(E) ;
3. Secured nipple(B) by ball tip(F) ;

