

MAXIM Assembly Instruction For 21569TWPN

1. Insert the bulb(A) into socket
2. Hang the crystal string(CRS21569PN-G),(CRS21569PN-F) to the metal ring(D) by mix
3. Hang the crystal string(CRS21569PN-D ,(CRS21569PN-E), (CRS21569PN-B) to the metal ring(C) by mix
4. Hang the crystal string(CRS21569PN- A),(CRS21569PN-C), (CRS21569PN-H) to the metal ring(B) by mix

