

XIM Assembly Instruction For 22304PN

- 1. Through the nut (C) to the metal washer (R), steel shade (O) and cross spider(D); then secured by ball (S) till tight
- 2. Secured the tube (J) to the nipple (K) till tight
- 3. Put the decorated part (H) and part (G) to the tube(J);
- 4. Secured the tube (E) to the tube (J)
- 5. Secured the tube (B2) to the tube (E)
- 6. Secured the tube (B1) to the tube (B2)
- 7. Secured the tube (B) to the tube (B1)
- 8. Secured the ceiling pan (A) to the tube (B)
- 9. Secured the nipple(Q) to the coupler (L); then secured by hex nut (P) till tight
- 10. Put the rubber washer (M1), glass diffuser (X), rubber washer (M) and metal washer (N) to the decorated flat metal; (Z), the secured by nut (V) till tight
- 11. Put the metal washer (W) and rubber washer (U) to the nipple (Q)
- 12. Put the glass diffuser (X) and decorated flat metal(\mathbb{Z}) into the steel shade(\mathbb{O}), and put the metal washer (W1) and rubber washer (U1) to the nipple (Q), then secured by the hex nut(P1) till tight
- 13. Put the cap (T) to the glass diffuser (X); then secured by part (Y) till tight
- 14. Install 5*60W type A bulbs into socket of the fixture(bulbs not included)



