

MAXIM Assembly Instruction For 24164SBUB

1. The nut(L) is through metal washer(K), cross spider (J), fabric shade(I), aluminum shade(H) and cap(G); then secured by ball(F) till tight
2. Secured the nipple(M) into coupler (A)
3. Put the poly body(B) on the nipple(M), then secured the arm component (C) with nipple together
4. Secured the finial(E) to the nipple(D) till tight
5. Install 5*60W type B bulbs into socket of this fixture(Bulbs not included)

