

1. Secure the center rod into the coupler.
2. Place the glass over the metal ring.
3. Take the arm then attached the loop 1 to the hook 1 and loop 2 to the hook 2.

