



Assembly Instruction For 2937,2938

1. Fixed the frame 1 on the large frame by the box screw 1
2. Fixed the frame 2 on the large frame by the box screw 2
3. Locked the tube 2 on the nipple 4
4. Locked the tube 2 on the nipple 3
5. Hang the hook into the loop
6. Fixed the 3 arms on the distributor by ball nut one by one, and fix it on the frame 1 by ball nut1 one by one
7. Fixed the 3 arms 1 on the distributor 1 by ball nut 3 one by one, and fix it on the frame 2 by ball nut1 one by one
8. Placed the cap and nipple 5 on the distributor 1, then secured by finial, as same the to fix the bottom cap and finial

