

## XIM Assembly Instruction For94160SBUB

- 1. Place the cap (B), aluminum shade(C), fabric shade(D), and metal washer(E), to the arm compenent (A); then secured by two side balls(F) till tight
- 2. Put the harp (H) to the socket(G); then secured by socket ring(I) till tight
- 3. Place the rubber washer(J), glass diffuser(K), rubber washer (J1) and metal washer(L) to the harp(H), then secured by hex nut(M) till tight
- 4. Put the cap(N) to the nipple of the harp(H); then secured by finial(O) till tight
- 5. Install 1\*60W type A bulbs into socket of this fixture(Bulbs not included)

